


Decals will need to be applied carefully over existing header panels. For best appearance and durability, it is recommended to:



1. Carefully remove the existing lipped molding along the top and bottom edges of the header panel.
2. Clean the surface of the existing header with Windex or similar glass cleaner.
3. Carefully align and apply the new oversized\* decal to the header panel.
4. Trim off the edges of the decal with a razor knife.
5. Carefully re-apply the lipped molding removed in step 1.

\* The decals are oversize by about one inch in width and one-quarter inch in height so they may be applied and trimmed to size.